



Fit 6mm cabin sides and roof panels before fitting front window panels (dry fit all parts before glueing in place)

Note allow for big bevel on front side window framing or glass/epoxy all joints



Ply foredeck panels fitted before fitting window panels  
Make scrap ply strip pattern for side window panels



Window/deck and window/roof joints can be timber or glass/epoxy

**Note; Photos show Skoota 20 not Skoota18!**

### **Skoota 18**

Building Manual 8

Copyright WOODS DESIGNS  
June 2017