



Typical Cross Section Cockpit Sole

bridgedeck is parallel to WL
 cut back bottom hull side panel as reqd
 after turning over
 Sheathing (green) optional but recommended
 It is simplest to preglass the panels before fitting

Chat18

7A Cockpit Sole

Copyright WOODS DESIGNS
 May 2016