



Cut wires to approx 80mm lengths, see note below  
 After basic assembly drill holes in bottom panel  
 to match side panel  
 Start at the transom and fit wires through holes  
 and twist together.  
 Initially only hand tight, then tension fully after  
 fitting a few wires.  
 At first fit every other wire then go back  
 and add wires as necessary.  
 Ensure the side piece lies on  
 top of the bottom panel,  
 that it is a snug fit and it  
 forms a fair curve



Note, you can use cable ties or  
 nylon fishing line instead of wire.  
 However the wires allow you to  
 adjust the tension, tight or loose, easily  
 I prefer copper wire as it is ductile,  
 steel wire tends to snap  
 After wiring up you should push  
 the wire tight against the hull  
 on the inside, see right  
 That way it is a smoother surface  
 when glassing  
 I usually use scrap household  
 solid electric wire.  
 You will need about 50m (150ft)

